



Preheat Effects on Shock Propagation in Indirect-Drive ICF Ablator Materials

R. Olson¹, R. Leeper¹, G. Rochau¹, J. Oertel², S. Evans², K. Lash²
S. Dropinski¹, D. Tanner¹, C. Russell¹, K. Cochran¹, P. Mix¹, A.
Nobile², G. Rivera², S. Haan³, R. Wallace³, J. Kaae⁴, A. Nikroo⁴,
Omega Operations Team⁵

¹Sandia National Laboratories, Albuquerque, New Mexico

²Los Alamos National Laboratory, Los Alamos, New Mexico

³Lawrence Livermore National Laboratory, Livermore, California

⁴General Atomics, San Diego, California


⁵University of Rochester, Rochester, New York

Third International Conference on Inertial Fusion Sciences and Applications
Monterey, CA, September 10, 2003





Cu-doped Be, Ge-doped CH, and polyimide are being considered as indirect drive ignition capsule ablators.



LANL Design:

D. C. Wilson, P. A. Bradley, et al.,
Fusion Tech., 38, 16 (2000).
R. W. Margevicius, et al., *Fusion
Tech.*, 35, 106 (1999).

¹LLNL and ²CEA Designs:


S. W. Haan, T. R. Dittrich, et al.,
Fusion Tech., 41, 164 (2002).
A. Nikroo, et al., *Fusion
Tech.*, 38, 58 (2000).
Ph. Baclet, et al., TFS Proc. (2003).

LLNL Design:

T. R. Dittrich, S. W. Haan, et al.,
Fusion Tech., 31, 402 (1997).
C. Roberts, et al., *Fusion Tech.*,
38, 94 (2000).


A Streaked Optical Pyrometer (SOP) views the UV emission when the shock breaks out at the ablator sample surface .

Be + 0.9% Cu Step




Time →

Be + 0.9% Cu Wedge ablator



Time →

$C_{38}H_{60}O_2$ & $C_{39}H_{57}O_2Ge_2$ Wedges



Time →

Omega halfraum




step or wedge
ablator sample

LANL Streaked Optical Pyrometer¹ (SOP)

Optics, mirrors, and
filters (280 nm bandpass)

streak camera

CCD




263 nm fiducial fiber

¹J. A. Oertel, et al, *Rev. Sci. Instrum.*, **70**, 803 (1999).




Features related to shock breakout, shock temperature, and pre-heat temperature are evident in the streaked SOP data.


**TIM-5 SOP
Omega shot 21858**



**Lineout comparison:
Omega shots 21858 & 27550**




The timing and intensity characteristics of the shock breakout and preheat features are repeatable on a shot-to-shot basis.



Spectral details are very important for the accurate calculation of shock timing and preheat in Cu-doped Be ablaters. Opacity and EOS calculations appear to be of lesser significance.

Variations on a Be+0.9%Cu shock breakout calculation



Shock breakout time and temperature and pre-heat temperature can be determined from the streaked UV image and compared to calculations.


	<u>> 1.5 keV</u>	<u>time</u>	<u>pre-heat</u>	<u>shock</u>
Tr calc	0.57%	1.9 ns	0.07 eV	8.0 eV
"NIF eq"	6.1%	2.2 ns	0.75 eV	12 eV
Exp calc	17%	2.5 ns	2.7 eV	16 eV
21858 data	--	2.4 ns	3.4 eV	15 eV
		+/- 0.1	+/- 0.2	+/- 0.8

(Aluminum step data is used as a standard to unfold the temperature from the SOP intensity data.)





The x-ray preheat has a significant effect upon indirect-drive ICF ablator shock velocity and shock temperature.

Omega SOP data for Be (0.9%Cu)
compared with Lasnex calculations




Sesame 2020 Be Hugoniot calculations
compared with data for Be (0.9%Cu)






Multi-sample shock/preheat experiments provide side-by-side ablator comparisons or same-shot Al wedge drive measurement.

29911 SOP image (Dec., 2002)




flat and wedge samples:

31820 SOP image (May, 2003)






two wedge samples:



Side-by-side comparisons indicate that Ge dopant has a significant effect upon x-ray preheat level and shock temperature in CH ablators.



SOP image

CH/Ge & CH wedges
1 ns sq. laser pulseCH/Ge & CH wedges
2 ns sq. laser pulse

The $\sim 8x$ reduction in preheat and $\sim 2x$ reduction in shock temperature are approximately consistent with Lasnex calculations.





The Al wedge SOP measurements indicated higher velocities than predicted by 2D integrated Lasnex.




The ~ 38 km/s Al shock velocity can be explained with a drive multiplier.




The Ge-doped CH shock velocity measurements have been ~ 12-15% lower than Lasnex calculations (2 ns sq).



Ge-doped CH shock velocities appear to be lower than Lasnex calculation, even though Al shock velocity is higher than Lasnex. This is also true for 1 ns sq experiments.




Variations on ignition capsule spectral input indicate that x-ray preheat can significantly alter capsule shock timing and yield.



at end of 3rd shock (~160 eV):
 % flux > 1.5 keV Yield (MJ)

1.6 %	18 MJ
6.1 %	16 MJ
15 %	5 MJ
22 %	0.1 MJ





Summary:

Omega experiments indicate that X-ray preheat ahead of an indirect-drive shock front causes significant shock propagation variations in Cu-doped beryllium, Ge-doped CH, and polyimide ablator samples.

We have experimentally demonstrated that dopants can be used to significantly alter (and perhaps control) the shock and preheat temperatures in x-ray driven ablator materials.

Ignition capsule sensitivity calculations indicate that drive spectra consistent with hohlraum albedo $\sim 80\text{-}90\%$ might result in significant yield degradation.

X-ray drive details in a full-size NIF ignition hohlraum will differ from the Omega situation, but this work indicates that an accurate understanding of ablator preheat will be essential for successful ignition of an indirect-drive capsule.

Sandia is a multi-program laboratory operated by the Sandia Corporation, a Lockheed Martin Company, for the U.S. Department of Energy under Contract No. DE-AC04-94AL85000.

