

# Life Cycle Testing and Evaluation of Energy Storage Devices

October 21, 2011

Summer Ferreira, Wes Baca, Tom Hund  
and David Rose

***Sandia National Laboratories***



Sandia National Laboratories is a multi-program laboratory managed and operated by Sandia Corporation, a wholly owned subsidiary of Lockheed Martin Corporation, for the U.S. Department of Energy's National Nuclear Security Administration under contract DE-AC04-

94AL 85000



# SNL Energy Storage System Analysis Laboratory

*Providing reliable, independent, third party testing and verification of advanced energy technologies for cell to MW systems*

## Testing Capabilities Include:

### Cell Testing

- Temperature chambers for thermal control
- 100+ cell and battery testing channels:
  - 72 V 1000 A Bitrode (2 Channels)
  - 60 V 200 A Arbin (2 Channels)
  - 36 V 100 A Bitrode (3 Channels)
  - 36 V 25 A Bitrode (5 Channels)
  - 10 V 10 A Arbin (48 Channels)
  - 5 V 3 A Arbin (48 Channels)



72 V 1000 A Bitrode (2 Parallel Channels)

### System Testing

- Temperature chambers for thermal control
- New Energy Storage Test Pad (ESTP) expands testing capabilities to include megawatt (MW) scale energy storage. This versatile facility is capable of testing in several configurations for many different applications.



Energy Storage Test Pad (ESTP) (April 2010)




# SNL Battery Abuse Testing Laboratory

*Battery testing, cell measurements, and materials development to support the development of inherently safe lithium-ion chemistries*

- Safety and abuse tolerance evaluation of energy storage devices from cells to kWh batteries:
  - Mechanical abuse
  - Thermal abuse
  - Electrical abuse
- Understanding degradation mechanisms that lead to cell failure
- Provide experimental data to support abuse and thermal modeling
- Cell prototyping facility for materials development

## Understanding abuse tolerance



50 Wh failure event



5 Wh failure event

# FY 2011 testing activities

## Cell Level Testing



East Penn Advanced  
Battery Cells  
(D. Enos 4:00 pm Thur.)



Altairnano Lithium-  
titanate oxide cells  
60 Ah and 11 Ah



International Battery  
Li-FePO<sub>4</sub> Cells

## Module Level Testing



East Penn Ultrabattery®  
Modules



Furukawa Ultrabattery®  
Modules



RedFlow 10kWh Zn-Br  
flow battery module  
(D. Rose 10:00 am Friday)



# FY11 Testing of Ultrabattery® modules




**East Penn**

- Both Ultrabattery® designs incorporate a supercapacitor in parallel with the negative electrode in a VRLA 12 cell, 1,000 Ah, 24V battery module.
- Tested with both a 'PV' and 'utility' cycle.





**Furukawa**

# Cycling protocols employed in testing




VRLA Life cycle data *S. Drouilhet, B.L. Johnson, 1997 NREL*



# East Penn Ultrabattery® performs much longer than VRLA

## PSOC utility cycling




- Ultrabatteries® 1,000 AH, 0.4 C and 0.3 C 5% PSOC cycling
- VRLA 30 AH, 1C 10% PSOC cycling
- Temperature rise in Ultrabattery® modules required reducing current for further testing



# East Penn Ultrabattery® performs much longer than VRLA

## PSOC utility cycling



Furukawa Ultrabattery® operated at elevated temperatures, leading to thermally activated degradation


East Penn Ultrabattery® shows no capacity loss after more than 13,000 cycles without recovering the battery

- Ultrabatteries® 1,000 AH, 0.4 C and 0.3 C 5% PSOC cycling
- VRLA 30 AH, 1C 10% PSOC cycling
- Temperature rise in Ultrabattery® modules required reducing current for further testing



# East Penn Ultrabattery® performs much longer than VRLA

## PSOC utility cycling





Furukawa Ultrabattery® operated at elevated temperatures, leading to thermally activated degradation

East Penn Ultrabattery® shows no capacity loss after more than 13,000 cycles without recovering the battery

- Ultrabatteries® 1,000 AH, 0.4 C and 0.3 C 5% PSOC cycling
- VRLA 30 AH, 1C 10% PSOC cycling
- Temperature rise in Ultrabattery® modules required reducing current for further testing



# Elevated temperatures occurred in Furukawa Ultrabattery®




Furukawa Ultrabattery® operated at elevated temperatures, leading to thermally activated degradation



# ★ Ultrabatteries® also perform much longer in PV cycling than VRLA

## PV Hybrid Cycle-Life Test



Even at 40 day deficit charge, Ultrabatteries® have performance far surpassing traditional VRLA batteries even with as low as a 7 day deficit charge (without recovery by taper charge).



# Cell level testing underway

## FY11 testing on battery cells

- International battery Li-ion  $\text{FePO}_4$  large format prismatic cells (160 Ah, 3.2 V)




- Altairnano lithium-titanate oxide cells (60 Ah and 11 Ah, 2.3 V)



# International battery cell capacity remains high after 15K+ cycles



International battery Li-ion  
 $\text{FePO}_4$  large format  
prismatic 160 Ah cells




Two International Battery cells  
currently operating under utility  
cycle testing protocol: 10% SOC  
cycles at 100 A current

**11% capacity loss after 15,000+ cycles**




## International battery cell performed well under aggressive abuse





Under overcharge abuse the cell vented and the case deformed but remained intact without catastrophic failure and thermal runaway did not occur.

# Characterization of Altairnano cells



Initial Capacity	$12.58 \pm 0.06$ Ah
3 Month Self-Discharge	$4.82 \pm 0.03\%$

Capacity as a function of T



Simon P , Gogotsi Y Phil. Trans. R. Soc. A  
2010;368:3457-3467

# Summary/conclusions to date

- **East Penn Ultrabattery<sup>®</sup> performs best in fast utility cycling, completing over 13,000 5% cycles with no loss in capacity.**
- **Furukawa Ultrabattery<sup>®</sup> performs best under deep DOD slow PV cycling, even at 40 day deficit charging.**
- **International Li-ion  $\text{FePO}_4$  cells have lost 11% of the initial capacity after over 15,000 10% cycles.**
- **Altairnano Li-titanate oxide cells have had initial characterization and will be cycled in FY12.**



# FY-12 testing activities

- Complete cycling of UltraBattery<sup>®</sup> modules and International Li-FePO<sub>4</sub> Cells

Continue Utility Cycle Test; end condition of 20% capacity loss or 365 days cycled

- Utility Cycle Altairnano Li-Titanate Oxide Cell

Utility Cycle Test end condition of 20% capacity loss or 1 yr is complete

- Bring flow battery testing online with:
  - Red Flow Zn-Br modules
  - CUNY Ni-Zn modules



A RedFlow 5 kW 10 kWh zinc-bromine flow battery module.



# SNL Energy Storage System Analysis Laboratory

*Providing reliable, independent, third party testing and verification of advanced energy technologies for cell to MW systems*

## Contact Information

Summer Ferreira  
srferre@sandia.gov

David Rose  
dmrose@sandia.gov

## Acknowledgments

- Thank you to Dr. Imre Gyuk for funding energy storage testing*
- Thank you to collaborating battery manufacturers*



**EAST PENN manufacturing co., inc.**



