The ASU-ISU collaboration on low temperature, high energy density, high efficiency liquid alkali metal storage cells

Towards Economical and Safe Storage of Solar and Wind Energy

C. Austen Angell and Steve W. Martin









TALK OUTLINE

- 1. What we planned originally, and how it didn't work
- 2. Identifying the problems
- 3. Doing something about it
 - (a) Changing to NaSICON separator

(b) Development of liquid redox cathodes

- (i) theoretical considerations.. The solvent basicity factor
- (ii) projecting the cell voltages
- (c) Testing the new cells
 - (i) the Fe(II)/Fe(III) redox cathode (at ASU)
 - (ii) the medium-temperature >100°C, aqueous Cu cathode
- 4. Future prospects


Original plan (optimistic)

Na-K phase diagram

Use

- (i) alkali metal alloys and
- (ii) ionic liquid electrolytes

To lower the working temperature of the liquid alkali metal storage cells (like ZEBRA) to ambient temperature.




Na-K phase diagram showing ambient liquids, 13 to 72at.% sodium, (from ASM 90146).

Na⁺ - rich electrolytes, high conductivity, σ ~0.1 S/cm @ T ~100


At ASU

Results:


Sodium ion trapping confirmed, but not too serious > 100°C



Walden Plot for ionicity



At ISU - a standard design Zebra cell for testing new ingredients under known conditions






At ISU


Results in Zebra cells

At ASU


Tube cell design with a Standard Catholyte



EXCELLENT PERFORMANCE




But with Low Temp IL Catholyte



Very Low Capacity



Testing at ISU using standard design




Possible problems

- Sodium doesn't wet ceramic at low T
- Beta alumina doesn't conduct well enough at low T
- NiCl₂ kinetics inadequate at low T
- Only single crystal β" alumina tolerates both Na and K ions

Traditional tublar ZEBRA battery works over 300 ℃

Is the problem in the "wettability" of the solid electrolyte by sodium?




Schematic for wetting of sodium on beta alumina/Nasicon at different temperature, (left) good wettability at high temperatures and Na⁺ can be transferred reversibly; (right) the wettability is poor at low temperatures and the Na⁺ can only transfer from cathode to anode, Na⁺ can not go back to cathode side.

Demountable flat panel design



Leigang Xue









spring metal shim cathode+electrolyte viton washer beta alumina copper wool+Na metal shim spring

WETTING Test: Use a low surface tension auxiliary Na⁺-carrying solution (NaClO₄/PC) to wet the NaSICON (as in the recent "hybrid" aqueous cathode cells)



Now, with NaClO4/PC to wet Nasicon

We can observe a cycle, but the kinetics are terrible! This has to be an NiCl₂ problem. The solution? **Abandon ship!**



Cyclic voltammograms of ZEBRA cell with Nasicon, 1 M NaClO4 in PC is used to wet nasicon. *Clear oxidation and reduction peaks of Ni2+/Ni* can be see at about 2.8 and 2.0 V. 70 °C

TALK OUTLINE

- 1. What we planned originally, and how it didn't work
- 2. Identifying the problems
- 3. Doing something about it.
 - (a) Changing to NaSICON separator
 - (b) Development of liquid redox cathodes
 - (i) theoretical considerations.. The solvent basicity factor
 - (ii) projecting the cell voltages
 - (c) Testing the new cells
 - (i) the Fe(II)/Fe(III) redox cathode (at ASU)
 - (ii) the medium-temperature >100°C, aqueous Cu cathode
- 4. Future prospects

So we need

- 1. Liquid cathode process that is reversible
- 2. Na-wettable separators


Recent literature:

the Fe(II) $\leftarrow \rightarrow$ Fe(III) + e-equilibrium in ionic liquid media:

Redox potential is highly dependent on solvent anion basicity. $\Delta E = 1.3 \text{ V}$!

Using standard data, Na + Ag +
$$\langle Na^+ + Ag \rangle$$


 $E_{cell} = 3.5 \text{ V}$



THE JOURNAL OF CHEMICAL PHYSICS 136, 244501 (2012)

Ionic liquids as oxidic media for electron transfer studies

Kazuhide Ueno and C. Austen Angell
Department of Chemistry and Biochemistry, Arizona State University, Tempe, Arizona 85287-1604, USA




Evaluating the possible cell emf

From standard textbook tables for a well-known oxidic medium, water

In acid medium, silver will oxidize ferrous iron to ferric meaning a Na/Fe(redox) cell with voltage above 3.5 V should be possible: (analog of LiFePO4)

Testing the concept with a CV (three electrode cell) and EMIFeCl₄-NaAlCl₄ (1:1)

$$Na + EMIFeCl_4 \xrightarrow{discharge} [EMI^+][FeCl_3^-] + NaCl$$




AlCl4- is the anion of a super acid.. i.e. it is an extremely weak base


Cyclic voltammograms of EMIFeCl4-NaAlCl4 with different voltage range, (a)-1.3 $^{\circ}$ 1.3 V; (b) -0.4 $^{\circ}$ 0.05 V. Pt as reference electrode, scan rate 10 mV s-1, T = 180 °C.

And now the cell, and the wetting problem





Solving the wetting problem




TALK OUTLINE

- 1. What we planned originally, and how it didn't work
- 2. Identifying the problems
- 3. Doing something about it.
 - (a) Changing to NaSICON separator

(b) Development of liquid redox cathodes

- (i) theoretical considerations.. The solvent basicity factor
- (ii) projecting the cell voltages
- (c) Testing the new cells
 - (i) the Fe(II)/Fe(III) redox cathode (at ASU)
 - (ii) the medium-temperature >100°C, aqueous Cu cathode
- 4. Future prospects


Now the cell test. CV in the cell and the cell voltage



The cell performance. Capacity is 70% of theoretical , but fading over 50 cycles


But the energy efficiency is outstanding > 96%





Safety issues: what happens if the ceramic cracks and direct mixing of catholyte and liquid sodium occurs?

Let's see.... (movie in low O₂ dry-box







Improvements to be tried

Avoid the formation of, and redissolution of NaCl


by using an extra mole of FeCl₃ (also should increase the cell capacity)

$$Na + EMIFe_2Cl_7 \xrightarrow{discharge} [EMI^+][FeCl_3^-] + NaFeCl_4$$

Extra Lewis acid raises the cell voltage to 3.7 V

Cathode: EMIFe₂Cl₇-NaAlCl₄ (1 : 0.2)

This should have an all liquid first stage, and **a second stage** that increases the capacity but is slower because of NaCl formation



- (+) $EMIFe_2Cl_7 + e^- + Na^+ \rightarrow EMIFeCl_3 + NaFeCl_4$ $NaFeCl_4 + e^- + Na^+ \rightarrow NaFeCl_3 \downarrow + NaCl \downarrow$
- (-) Na \rightarrow Na⁺ + e⁻

TALK OUTLINE

- 1. What we planned originally, and how it didn't work
- 2. Identifying the problems
- 3. Doing something about it.
 - (a) Changing to NaSICON separator

(b) Development of liquid redox cathodes

- (i) theoretical considerations.. The solvent basicity factor
- (ii) projecting the cell voltages
- (c) Testing the new cells
 - (i) the Fe(II)/Fe(III) redox cathode (at ASU)
 - (ii) the medium-temperature >100°C, aqueous Cu cathode
- 4. Future prospects

Hao Liu and Steve W. Martin at ISU; the >100°C aqueous copper cathode cell

- Anode: empty
- Cathode: 5.5 M NaCl + 5.5 M ZnCl₂
 aqueous solution, copper wool filling
- Total cell reaction:


 $2NaCl + Cu \Leftrightarrow 2Na + CuCl_2$

charging

theoretical voltage:


2.805 V @ 103°C and 1s charging time

The planar cell (identical to the ASU cell), and the initial tests



2.7 V OCV with little charging overvoltage: some side reaction?

Noisy data but no capacity or coulombic efficiency fade



Average coulombic efficiency is about 80% in 100 cycles.

Other degrees of freedom

- 1. The ionic liquid Fe(redox) cell
 - (i) Other transition metal redox couples
 - (ii) Other ionic liquid cations of higher chemical stability.
 - (iii) Other lower cost Na wetting agents Fe...
- 2. And the >100°C aqueous brine cell being tested at ISU
 - (i) Other transition metal redox couples
 - (ii) Other (lower cost, non-toxic) spectator salts for vapor pressure lowering
 - (iii) Other lower cost Na wetting agents Fe...

Summary

- 1. ZEBRA cell shown impractical at low temperatures
- 2. New liquid cathode cells developed that work well in the low temperature range
 - (a) Na- Fe (redox) cell in ionic liquid electrolyte at 180°C OCV = 3.3 -3.5 V high energy efficiency, cheap and fail-safe
 - (b) Na-Cu cell at 103°C OCV = 2.8 V

 Potential to reach really high C rates. Many degrees of freedom to explore