

Advances in PNNL's Mixed Acid Redox Flow Battery Stack

David Reed, Ed Thomsen, Wei Wang, Zimin Nie, Bin Li, Brian Koeppel, Kurt Recknagle, and Vincent Sprenkle.

Pacific Northwest National Laboratory
Electrochemical Materials and Systems

DOE Office of Electricity Energy Storage Program – Imre Gyuk
Program Manager.

OE Energy Storage Systems Program Review
September 16-19th, 2014



Topics

- ▶ FY 14 Objectives and Goals
- ▶ Background
- ▶ Nafion® membrane thickness development.
- ▶ Low cost interdigitated flow design
- ▶ 4 KW stack
- ▶ Conclusion and Future Work


FY14 Redox Objectives and Goal

- ▶ Operate at 240 mA/cm² with improved stack energy efficiency and lower stack pressure drop.
- ▶ Greater stack efficiency
 - Use of 212/211 membrane versus 115.
- ▶ Greater system efficiency
 - Use of interdigitated flow field
- ▶ Understand influence of temperature on stack efficiency

Vanadium Mixed Acid Electrolyte



- Power and Energy are separate enabling greater flexibility and safety.
- Suitable for wide range of applications 10's MW to ~ 5 kw
- Wide range of chemistries available.
- Low energy density ~ 30 Whr/kg




V^{5+} in sulfuric acid
-- $[\text{VO}_2(\text{H}_2\text{O})_3]^+$

V^{5+} in mixed acids --
 $\text{VO}_2\text{Cl}(\text{H}_2\text{O})_2$


- **70% increase in capacity**
 - V^{2+} , V^{3+} , V^{4+} , V^{5+} stable >2.8M, in SO_4^{2-} and Cl^- mixed solutions
- **80% increase in operating temperature window.**
 - $-5 - 50^\circ\text{C}$

Redox Flow Battery Objectives


Develop the technologies, tools, and system understanding required to move the mixed acid electrolyte chemistry from basic chemistry to cost effective system solution.



Basic Chemistry



Applied Systems



FY14 Stack Performance (Nafion® 115, 212 and 211)




VRFB System

Test Parameters

- 780 cm^2
- 3 cell stacks
- 15-85% SOC
- Mixed acid electrolyte
 - 2M V, 2M S, 2M Cl
- Nafion® membrane
 - 115 (~ 5 mil)
 - 212 (~ 2 mil)
 - 211 (~1 mil)
- $j = 160 \text{ and } 240 \text{ mA/cm}^2$
- Flow through design

FY14 Stack Performance (Nafion® 115, 212 and 211)




@Flow Rate = 6 lpm (400 cc/min/cell)


	Columbic	Voltage	Energy	Discharge	Discharge	Pressure
	Efficiency (%)	Efficiency (%)	Efficiency (%)	Capacity (Ah)	Temp (°C)	(psi)
160 mA/cm²						
Nafion® 115	96.9	77.7	75.3	18.2	39.9	6.5
Nafion® 212	97.9	82.9	81.2	19.2	39.9	6.9
Nafion® 211	96.9	84.0	81.4	20.1	38.8	6.9
240 mA/cm²						
Nafion® 212	98.0	76.5	75.0	16.7	44.6	6.1
Nafion® 211	97.0	77.8	75.5	18.1	45.5	5.9

FY14 Stack Performance (Nafion® 115, 212 and 211)

Capacity Fade



Cost*



* Ion Power, Inc – based on 20 m length


- ▶ Substitution of Nafion® 212 and 211 for 115 in 3-cell stack leads to
 - ~5 - 10% increase in Energy Efficiency (≥ 160 mA/cm²)
 - Similar capacity fade
 - Cost reduction
- ▶ Nafion® 211 more difficult to handle

FY14 Stack Performance (Low Cost IDD Flow Design)


Flow Through Design




(FTD)



IDD Flow Design




(IDD 1)





Low Cost IDD Flow Design



(IDD 2)




FY14 Stack Performance (Low Cost IDD Flow Design)



- ▶ Higher flow rates with IDD 1 and IDD 2
- ▶ IDD 1 approximately 3X material cost
- ▶ Sealing issues with IDD 1

FY 14 VRFB 4KW Performance





VRFB System

Test Parameters

- 780 cm^2
- 20 cell stack
- 15-85% SOC
- Mixed acid electrolyte
 - 2M V, 2M S, 2M Cl
- Nafion[®] membrane
 - 212 (~ 2 mil)
 - $j = 160 \text{ and } 240 \text{ mA/cm}^2$
- Low cost interdigitated flow design
- 4 KW stack
- Chillers to control temperature

FY 14 VRFB 4KW Performance

20 Cell Stack – 50 °C , 800 cc/min/cell, Nafion® 212




- ▶ 5% reduction in Stack Energy Efficiency
- ▶ 30% increase in Power


FY 14 VRFB 4KW Performance

20 Cell Stack – 240 mA/cm² Nafion ® 212

Efficiency vs Temp





Efficiency vs Flow Rate



- Flow rate and temperature both improve stack energy efficiency

FY 14 VRFB 4KW Performance

20 Cell Stack – 50 °C , 800 cc/min/cell, Nafion® 212



- ▶ Stable performance for mixed acid electrolyte observe over a broad range of temperatures and flow rates

Summary/Conclusions

- ▶ Substitution of Nafion[®] 212 or 211 for 115 in 3-cell stack leads to
 - ~5 - 10% increase in Energy Efficiency ($\geq 160 \text{ mA/cm}^2$)
 - ~ 50% cost reduction
- ▶ Low cost IDD had similar performance to original IDD but has a substantial reduction in material cost
- ▶ The 4kW class – 20 cell stack operated at 240 mA/cm^2 resulted in
 - ~ 30% increase in power
 - 5% reduction in energy efficiency (75%)
 - Stable performance over a range of temperatures and flow rates using the mixed acid electrolyte

Acknowledgements

- ❑ DOE-OE Energy Storage Program, Dr. Imre Gyuk