

# High-temperature, Large Format Focal Plane Arrays For Emerging Infrared Sensing Applications




## Sandia National Laboratories

Jin Kim, Richard Cernosek, Mike Cich, Torben Fortune, Aaron Gin,  
Samuel Hawkins, John Klem, Sayan Mukherjee, Rohit Prasankumar, Jeff Rienstra,  
Prashanth Upadhy, Inès Waldmueller

### Problem

#### Project Overview: the Science



### Approach



#### Understand SLS Theory

##### Why?

- Predict Energy Levels: effective  $E_g$ ,  $E_c-E_v$  offsets, heterostructures (static)
- Study non-ideal interfaces, atomistic defects (empirical pseudopotential method)
- Parametric Fitting: Aid nBn device design and modeling
- Quantify absorption rates, carrier lifetime (dynamic)

##### Methodology:

- Empirical pseudopotential method (EPM)
- Semiconductor Bloch equations
- Maxwell's equations



### Approach (cont.)

#### Carrier Lifetime Measurements

##### Why?

- Carrier lifetimes ( $\tau$ ) represent characteristic generation mechanisms  $\Rightarrow I_{\text{dark}}$
- Provides device-independent material quality assessment
- Reconciling modeled/measured  $\tau$  permits estimation of defect density/type.

##### Methodology: THz pump-probe


- Varying pump energy: selective pumping of GaSb, InAs, and/or SLS
- THz probing: directly translates to time-dependent carrier density
- Currently limited to 3 ns, working on to extend to 1  $\mu$ s

	Sample	Periods	InAs	GaSb	Cladding	Variation
1st Set	G252		1000 nm		none	
	G283		50A		AlAsSb	InAs surrounded by AlAsSb
	G284				AlAsSb	like G283, just cladding
	G288	10 pairs	8 ML	8 ML	AlGaSb	baseline SLS
2nd Set			50 A		AlGaSb	different cladding
		10 pairs	8 ML	80 ML	AlGaSb	exaggerate effects of GaSb
		10 pairs	8 ML	8 ML	AlGaSb	add As in GaSb
		10 pairs	8 ML	8ML	AlGaSb	GaInSb (redshift)

All samples have sacrificial InAsSb etch stop layers.

### Results


#### 800nm ~50fs Pump – THz Probe



##### Experimental setup for ultrafast wavelength-tunable pump-probe spectroscopy

- Laser source is a Coherent RegA ultrafast amplifier system producing ~50 fs pulses at 800 nm with ~10  $\mu$ J energy/pulse and 100 kHz repetition rate
- Nonlinear ZnTe crystals are used for generation and detection of THz radiation
- The "Gate Pulse" is used for the coherent detection of THz pulses via electro-optic sampling technique
- Accurate measurements of low-level THz signal amplitude change is accomplished using a polarization sensitive detection scheme involving lambda/4 plate, Wollaston prism and balanced photo-detectors

#### Room-T Carrier Lifetime Measurement



### Significance

#### Sample Fabrication

##### Advances in Fabrication

- <100 nm membranes can now be suspended on THz transparent holder.
- Stable after temperature cycle to 77 K
- Oxidation mechanisms of AlAsSb under investigation.

