
Enhanced spontaneous emission rate in visible III-nitride LEDs using 3D photonic crystal cavities.


Project Manager: James Hudgens
Principal Investigator: Arthur Fischer

Investment area: Electronics and photonics

1D Photonic crystal



2D Photonic crystal



3D Photonic crystal



<u>Co-investigators:</u> Ganesh Subramania, Ting Shan Luk, Dan Koleske, Yun-Ju Lee, Qiming Li, George Wang, Kris Fullmer, and Anthony Coley.

Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company, for the United States Department of Energy under contract DE-AC04-94AL85000.




SAND Number: 2009-5157 P




Photonic Density of States and Light Emission

Emitter in free space




- Emitter couples to free space radiation modes
- Emitter decays with natural, fixed radiative rate (R_r)

Emitter in environment with altered photonic density of states



- Emitter couples to different radiation modes
- Radiative rate can be increased or decreased
- Photonic crystals, surface plasmons, etc...

Fermi's Golden Rule:



Purcell Effect:

$$F = \frac{3Q_m g(\lambda/2n)^3}{2\pi V_{eff}}$$

n = index

g = degeneracy l = wavelength Q = quality factor V = mode volume

Ultimate control over when and if a photon is emitted





3D photonic crystal: density of states

Radiative decay rate (dipole in a PC at coordinate 'r')




$$\Gamma_{\rm rad}(\mathbf{r}) = \frac{\pi \omega \mu^2}{3\hbar \epsilon_0} N_{\rm rad}(\mathbf{r}, \, \mathbf{d}, \, \omega)$$

Local radiative density of states (LRDOS)




$$N_{\text{rad}}(\mathbf{r}, \mathbf{d}, \omega) = \frac{1}{\epsilon(\mathbf{r})} \sum_{n, \mathbf{k}} 2\omega \delta(\omega^2 - \omega_{n, \mathbf{k}}^2) |\mathbf{d} \cdot \mathbf{\Lambda}_{n, \mathbf{k}}(\mathbf{r})|^2$$
$$\mathbf{\Lambda}_{n, \mathbf{k}}(\mathbf{r}) = (\nabla \times \mathbf{H}_{n, \mathbf{k}}(\mathbf{r})) / (\sqrt{\epsilon(\mathbf{r})} i\omega_{n, \mathbf{k}})$$

Photon Density of States in a 3D PC*



- Enhancement
- Suppression





- → 3D PCs offers complete light control
- → Density of states is position dependent
- → Emitter placement inside PC is crucial

*T.Suzuki et. al., JOSA-B, **12**, 570 (1995)






Light Control In Nature Via Nanostructuring

Morpho Butterfly

(M. Sulkowskyi)



- Photonic Crystal structures in butterfly wings.
- Color response highly sensitive to different vapors
- Signals by giving off colors by strong reflection of sunlight: visible half mile away



(M. menelaus)

Passive control of light sources to suit one's requirements

* R.A. Potyrailo et. al., Nature Photonics, 1, 123 (2007)








Light emission control with photonic crystals


Photonic Crystal Nanostructures

Light Sources (QDs, Qwires, thermal)












Modify emission
behavior: Sources
with novel and improved
functionalities







Array of TiO₂ rods



TiO₂ logpile PC

- High brightness/efficiency
- Tunable
- Directional, compact


- Anti-bunched
- Entangled








1D microcavity with GaN emitter

FIB-SEM image → 1D HfO₂/SiO₂ cavity















1D microcavity with GaN emitter: photoluminescence

- Laser-lift-off process is used to remove sapphire substrate
- 8 pair SiO₂/HfO₂ mirror used to form cavity
- GaN high Q cavities can lead to exciting new physics studies
 - Strong coupling, polaritons
 - Room temperature Bose-Einstein condensates
- DBR microcavity suppresses emission from GaN epilayer
- Dramatic change in lifetime observed

Time-resolved Photoluminescence



Time-integrated Photoluminescence









Visible TiO₂ Logpile 3D Photonic Crystals


White light microscope images (5 layer sample)




TiO₂ index of refraction




SEM images (9 layer sample)









Reflectance from 9-Layer Visible TiO₂ Logpile



- Near normal incident reflection data
- Nine layer structure with lattice constant a=250 nm
- Bandgap extends from 400 to 500 nm
- Reflection greater than 80% → excellent morphology
- Demonstrates that TiO₂ PCs can be used at 400 nm



Reflection- Perpendicular Polarization








3D photonic crystal 'air defect' microcavity

Geometry: 9 layer structure with microcavity defect in the 5th layer

- Portions of rods removed to create 'air' defect cavities
- Fabricate bottom 5 layers first and then the top 4 layer separately on a transparent substrate (sapphire)
- •Enables introduction of light emitters (e.g. QDs) post fabrication using chemical functionalization (already developed)
- •Evaluate cavity modes: resonance frequency, Q factor
- Small modes volumes and high Q are desired










FDTD modeling of microcavity reflectance


FDTD conditions:


- Supercell: 5 unit cells
- Cavity defect periodic with 5 unit cells
- Periodic boundary conditions in the transverse
- Gaussian source

Cavity A: Every 5th rod removed

- Q factor ~ 30
- Mode volume : 2*(I/n)3















FDTD modeling of microcavity reflectance









- Q ~ 250
- MV : 0.25(I/n)³








- Q ~ 300
- MV : 0.42(I/n)³





Fabricated TiO₂ Photonic Crystal Cavities









Combine 3D photonic crystals and InGaN LEDs


3D photonic crystals



- Use InGaN LEDs as a test case for enhanced spontaneous emission.
- Merge InGaN LED research with 3D photonic crystal research.
- Sandia is a recognized world leader in both areas.
- Both research areas will benefit.
 - GaN is an attractive dielectric for 3D PBG work.
 - InGaN LED efficiency enhancements benefit SSL

InGaN LEDs






InGaN LED array incorporated into a 3DPC






Incorporation of emitters: InGaN nanopost LEDs

loose-packed nanopost LED array




- Fabricated InGaN nanopost LEDs
- Arrays were fabricated such that a 3D logpile PC could be formed around posts.
- Difficult to electrically connect LEDs
- Original plan was to incorporate InGaN nanopost LEDs in 3D PCs
- Better methods of emitter incorporation were developed as a part of this program

close-packed nanopost LED array



EL from one (or a few) nanopost LEDs








Self-assembled Monolayer of CdSe on TiO₂


- 1. Coat TiO₂ logpile with neat 3-mercaptopropyltrimethoxysilane (70 °C, 3 min)
- 2. Rinse with chloroform
- 3. Bake logpile on hot plate to form linkage (120°C, 30 min)
- 4. Place TiO₂ logpile in TOPO-capped CdSe in toluene (RT, 1 hr)



Bake to form self-


assembled monolayer (SAM)

P. Guyot-Sionnest and C. Wang, J. Phys. Chem. B, 107, 7355 (2003) J. Pacifico, D. Gomez, and P. Mulvaney, Adv. Mater. 17, 415 (2005)



Submerge in CdSe suspension to exchange ligands






Rinse off unattached CdSe





PL Response of CdSe QDs Inside the PC


- Incorporated CdSe quantum dots into TiO₂ 3D logpile structures
- Developed Aerogel + quantum dot infiltration process
- PL is enhanced for 400 nm lattice constant (outside band gap)
- PL is suppressed for 350 nm lattice constant (inside band gap)
- 3D photonic crystal is effective at controlling photon emission








Fabrication of all GaN Vis-UV Logpile PC




GaN grows uniformly throughout structure




3. Grow GaN by MOCVD

Transparent to 365nm Index ~ 2.5

1. Fabricate Si logpile with SiO₂ background still in place



2. Etch out Si using KOH leaving SiO₂ skeleton in place




4. Remove SiO₂ template to leave behind GaN logpile





All GaN Vis-UV Logpile Photonic Crystal


SEM images of GaN PC



Implications of GaN logpile PC:

- Demonstrated all GaN 3D PC structure
- Important step forward for visible PCs
- Extremely good transparency across entire visible spectrum and into UV
- Potential to demonstrate shortest 3D PC
- Incorporate InGaN emitters, n-type and p-type
- Clear path to an electrically-injected 3D photonic crystal light source

Reflectivity from GaN PC sample








Impact of 3D photonic crystal research

Example Application Area:

- → High efficiency lighting (SSL)
- Efficiency gap between nitrides and phosphides (green gap)
- Utilize changes to photonic density of states to increase efficiency
- Increase radiative rate to better compete with non-radiative




Significance of Results


- Advance our understanding of interaction between semiconductor emitters and 3D photonic crystals.
- Develop new fabrication methods for visible 3D photonic crystals.
- Pave the way for investigation of exciting new areas of physics research:
 - Polariton dynamics, strong coupling
 - Solid state Bose-Einstein condensation
- Enable the development of advanced photon sources for applications such as optical and quantum computing.
- Control photon emission processes at an new and unprecedented level.
- Create solid state light sources with new functionality:
 - High Brightness/Efficiency
 - Single/Entangled Photon Sources
 - Directional, Compact
 - Anti-bunched Photons





Summary





Accomplishments:

- Developed a method of fabricating 3D logpile photonic crystal structures made from TiO₂ for use in the visible.
- Incorporated GaN and quantum dot emitters in photonic crystal cavities and investigated luminescence properties.
- Demonstrated changes to luminescence intensity as well as radiative lifetime for emitters inside photonic crystal cavities
- Demonstrated control of light emission via altered photonic density of states.
- Developed a new method to fabricate UV/visible 3D photonic crystal structure made totally of GaN material.
- Funded follow-on project to investigate strong coupling and polariton condensates in GaN microcavities (BES-EFRC)
- 5 journal publications and 7 conference presentations

