


Lanthanum Enhanced DE Nanocrystalline Media (NXT)



10/19/04

Agenda

EaglePicher™
Filtration & Minerals

- ❑ Who is EP?
- ❑ What is NXT Media?
- ❑ Benefits
 - Technical Data Sustaining Results
 - How is it Made?
- ❑ Testing History
 - Laboratory
 - Fernley, NV Pilot Test Results
- ❑ NXT Adsorption Media Update

Who is EaglePicher?

EaglePicher™
Filtration & Minerals

- ❑ Leading Supplier of DE with Over 60 Years of Experience in the Filtration of Food Grade Products
- ❑ Common Applications:
 - Soft drinks
 - Fruit juices
 - Beer and Wine
 - Animals and Vegetable Oils
 - Sweeteners
- ❑ Customers:
 - Cargill
 - Tate & Lyle
 - SAB (Miller)
 - Pepsi Co.
 - Welchs



Making Use of the Best Available Technologies


EaglePicher™
Filtration & Minerals

- ❑ Coagulation / Filtration: NXT Precoat Media
 - Pilot tested in Fernley Nevada using Precoat Pressure Filter
 - Further Testing on Rotary Vacuum Precoat Filtration Demonstrated Improved Economics over Pressure Filter by \$.03/1000 gallons
 - \$.30-0.40/1000 gallons treated
- ❑ Adsorption: NXT Adsorption Media
 - Currently in Final Stages of Development
 - Modified Precoat Media
 - RCSST Testing in Process
- ❑ Ion Exchange
- ❑ Reverse Osmosis


NXT Media: What is it?

EaglePicher™
Filtration & Minerals


Naturally
occurring
diatomaceous
earth (DE)



DE is a mineral
of organic
origin. It
represents the
accumulation of
many different
kinds of fossils.




La/Fe
Coated DE



Characteristics of NXT Media

EaglePicher™
Filtration & Minerals

- ❑ Surface area of the coated material is estimated to be 100 m²/gm
- ❑ Factors for efficient removal of arsenic from water:
 - High surface area
 - Positive surface charge (up to pH 10.0)
 - Inter-particle filtration behavior of DE
- ❑ The crystalline nature of precipitate and strong bonding between the adsorbent and arsenic species allow the arsenic to be tenaciously bonded to the materials.




NXT Benefits

EaglePicher™
Filtration & Minerals

- ❑ Cost Efficiency
 - Effective over wide pH range
 - Not selective of state, removes oxidation step
- ❑ Safe
 - Will not release bound arsenic if pH upset occurs
 - Spent cake meets TCLP and Cal wet test requirements for non-hazardous material*
- ❑ Versatile
 - Removes more than arsenic, phosphates, chromium, selenium and pathogens*
- ❑ Stability
 - Long Shelf Life

Effective over a Wide Range of pH


EaglePicher™
Filtration & Minerals



Zeta Potential of DE and Hydroxy-gel

Why La-Fe-Arsenate is Better?

EaglePicher™
Filtration & Minerals




Stability of Precipitated Lanthanum Arsenate/ Ferric Arsenate as a Function of pH


Why pH is Important

In natural waters arsenic is found as Arsenite [As(III)] and Arsenate [As(V)].

Arsenite (As⁺³)




Arsenate (As⁺⁵)



Arsenite Species Distribution

EaglePicher™
Filtration & Minerals



Testing History


EaglePicher™
Filtration & Minerals


❑ Batch test

- Ex-situ and In-situ methods comparison for removing arsenic from synthetic solution
- Fernley groundwater ex-situ and in-situ methods comparison


❑ Continuous


- Pilot scale test performed at Fernley water treatment plant






Bench-scale tests showed that both the arsenate and arsenite species can be effectively removed from drinking water using hydroxy crystals coated onto DE







The material prepared by the in-situ method is invariably more effective than ex-situ method



Arsenic Removal from Synthetic Solution (Continuous Test)




Arsenic Removal from Fernley Well Water (Pilot Test)



Pilot Test Results

EaglePicher™
Filtration & Minerals



- ❑ The material prepared by the in-situ method is invariable more effective than ex-situ method
- ❑ Fernley water 43-57 ppb As

Pilot Site – Fernley, NV

EaglePicher™
Filtration & Minerals



Operated at a flow rate of 12-15 gallons/min.

DE Precoat Filtration

Fernley, Nevada Pilot Method

EaglePicher™
Filtration & Minerals

- ❑ DE filtration is a two-step operation. In the “precoating” operation, a thin layer of clean filter aid is coated on the filter element by recalcitrating a dilute slurry of filter aid through the filter.
- ❑ A small amount of filter aid is continually added to the liquid being filtered. As the filter cycle progresses, the bodyfeed produces a fresh new filtering surface to entrap particles and also provides microscopic channels through which the clarified fluid can flow.

Summary of Pre-coat Filtration Technology


EaglePicher™
Filtration & Minerals

- ❑ De coated hydroxide in conjunction with pre-coat filtration has demonstrated potential for the treatment of arsenic in well waters
- ❑ This method is cost effective and efficient in meeting the proposed Federal drinking water limits of 10 ppb arsenic
- ❑ Bench-scale and pilot test have established that the arsenic treatment cost is estimated to be \$0.30-0.40 per 1000 gallons
- ❑ The process is effective in removing arsenite and arsenate within a pH range of 6.5-8.5
- ❑ The arsenic containing DE sludge after treatment meets TCLP standards for disposal

La-DE and/or La-Fe-De Adsorption Process

EaglePicher™
Filtration & Minerals


- ❑ Based on the bench and pilot test results, EaglePicher believes the fundamental principle for arsenic removal by DE-La or DE-La-Fe precoat filtration technology can be applied to adsorption as well.
- ❑ EaglePicher has conducted RSSCT with La-DE and currently performing another RSSCT with La-Fe-DE for removing arsenic from drinking water




Adsorption Testing

- Bench testing
 - Screening adsorbent based on DE size for RSSCT
- Rapid small scale column testing (RSSCT)
 - La-DE
 - RSSCT using La/Fe-DE material is in progress

**SEM Picture of La/Fe/De
(300°C)**



Adsorption Bench Results



❑ **MPC32/100 & MPL10/32 have been selected for RSSCT**

- ❖ **MPC32/100 is Lanthanum-Iron Enhanced 150-450 microns DE Nanocrystalline media**
- ❖ **MPL10/32 is Lanthanum Enhanced 500-710 microns DE Nanocrystalline media**


La-DE POU Test

□ Test conditions:

- Arsenic species in water: As^{+3}
- Arsenic Concentration: 100 ppb
- pH of water: 7.2
- Surface area of adsorbent: 101 m²/gm
- Bed volume: 100 cc
- Flowrate: 100 cc/min
- EBCT: 60 sec

Test Results – To Date

EaglePicher™
Filtration & Minerals



Initial Testing Looks Promising

Thank You